



Kids Pusher Arcade Shooting Gun Game Machine Coin Operated Games Gun Shoot Machine

Our Product Introduction

for more products please visit us on coingamesmachines.com

Basic Information




Product Specification

- Highlight: Coin Pusher Kids Game Machine, Coin Operated Kids Game Machine, Kids Arcade Shooting Game Machine



More Images



Product Description

How to play:

1. Coin press the start button to start the game.
2. Aim the gun at the game screen and select the scene. There are 4 scenes to choose from. Aim at monsters in the game scene, kill monsters to gain points.
3. At the end of the game, reach the specified score can get twisted egg

Product Name	Jed gunlord
Size	120*129*156
Player	1 Player
Weight	80KG

