



Coin-operated indoor park children's shooting 4-person arcade entertainment water shooting 6-in-1 arcade game machine

Our Product Introduction

for more products please visit us on coingamesmachines.com


Basic Information



Product Specification



More Images



Product Description

Coin-operated indoor park children's shooting 4-person arcade entertainment water shooting 6-in-1 arcade game machine

How to play

1. Sit down and insert coins to start the game.
2. Move the gun to shoot to select the map.
3. During the game time, shoot the game to win more points.
4. The higher the score, the more lottery tickets you win.

Product name	Crisis Rescue water shooting
Size	198*246*270cm
Weight	125KGS
Material	Metal + Plastic

Our Product Introduction

for more products please visit us on coingamesmachines.com

